








# Chromebooks - additional support information

## Use the multi-touch screen

Lenovo 300e/500e Chromebook 2nd Gen supports the multi-touch function. Some gestures might not be available depending on the app you use.


	<p><b>Tap</b></p> <p>Open an app or perform an action on an open app, such as <b>Copy</b>, <b>Save</b>, and <b>Delete</b>, depending on the app.</p>		<p><b>Tap and hold</b></p> <p>Open a shortcut menu.</p>
	<p><b>Slide</b></p> <p>Scroll through items, such as lists, pages, and photos.</p>		<p><b>Drag an item to the location you want</b></p> <p>Move an object.</p>
	<p><b>Move two fingers closer together</b></p> <p>Zoom out.</p>		<p><b>Move two fingers farther apart</b></p> <p>Zoom in.</p>
	<p><b>Swipe up from the bottom</b></p> <p>Unfold the APP Launcher.</p>		<p><b>Tap with two fingers</b></p> <p>Open a shortcut menu.</p>

## Use the touchpad gestures




### Tap

Tap anywhere on the touchpad with one finger to select or open an item.




### Two-finger tap

Tap anywhere on the touchpad with two fingers to display a shortcut menu.



### Two-finger scroll

Put two fingers on the touchpad and move them in the vertical or horizontal direction. This action enables you to scroll through the document, Web site, or apps.



### Swipe three fingers up or down

Put three fingers on the touchpad and move them up or down to see all your open windows.